

# APRA Users Manual



*PerfectFlite*



# **APRA Users Manual**

A miniature, high accuracy altimeter for rocketry.



PO Box 29  
Andover, NH 03216  
Voice (603) 735-5994  
FAX (603) 735-5221

URL: [www.perfectflite.com](http://www.perfectflite.com)  
Sales: [sales@perfectflite.com](mailto:sales@perfectflite.com)  
Support: [support@perfectflite.com](mailto:support@perfectflite.com)

# Contents

<b>Introduction</b> .....	1
<b>Parts Identification Diagram</b> .....	2
<b>Installation</b>	
Payload Bay Construction.....	3
Static Pressure Sampling Ports.....	5
<b>Operation</b>	
Installing Battery.....	6
Power Switches.....	6
Numerical Reporting.....	7
Powerup Sequence.....	8
Tips for Achieving Optimal Accuracy.....	9
Testing.....	11
Cautions.....	11
<b>Specifications</b> .....	12
<b>Warranty</b> .....	Back Cover

## Introduction

The *APRA* (Affordable Precision Rocket Altimeter) is a high-quality rocket altimeter that doesn't sacrifice accuracy despite its low price. It is extremely easy to use, yet provides the same phenomenal accuracy as our more expensive full featured altimeters. It is ideal for introductory rocket education, science fair data collection, and contest use.


The *APRA* is installed inside your rocket and activated prior to launch. When you retrieve your rocket, the *APRA* will report the apogee altitude (how high your rocket went, up to 100,000 feet above ground) and the maximum velocity (how fast your rocket went, in miles per hour). It uses a convenient, easy to understand audio reporting method that is audible from outside your rocket, so removal or inspection of the altimeter is not necessary. The reported altitude and velocity are alternated with a 10 second siren sound that helps to locate your rocket even if it is hidden in tall grass or a tree.

If you need additional features, you may want to consider the PerfectFlite *Pnut*, which is smaller than the *APRA*, has a built-in rechargeable battery, and stores complete flight data (altitude, temperature, and battery voltage) from your last 31 flights. The data can be downloaded to a computer for storage, graphing, and additional manipulation. Or for even more versatility, the PerfectFlite *StratoLogger* combines this flight data download feature with two event electronic parachute deployment for advanced users. Electronic deployment provides the ultimate in control over when your parachute is ejected – no more guessing about which ejection delay length to use, the altimeter will always fire precisely at apogee.

The *APRA* utilizes a precision pressure sensor and 24 bit delta sigma analog to digital converter to obtain an extremely accurate measurement of the air pressure surrounding your rocket. When turned on, the altimeter “tracks” the ambient pressure surrounding your rocket to get an up-to-the-second reading of the barometric pressure at ground level. As the rocket rises, the pressure decreases, and the altimeter converts the pressure differential to a precise measurement of altitude above launch point according to the US Standard Atmosphere model. All of the calculations are done inside the altimeter, with the results reported simply as “altitude above ground level”. No conversion or adjustment is necessary.

### ***Parts Identification***

Refer to the top of the altimeter to locate the following items:




- A) Beeper: Audibly reports altitude and velocity after flight.
- B) Battery Holder: Uses type A23 12 volt battery. *Polarity (+/-) must be correct or altimeter will not power up. Reverse polarity will not damage the altimeter.*
- C) Power Pins and Jumper Shunt. *Shunt shown in storage (“off”) position. Place shunt across both pins to turn altimeter “on”.*

# Installation

For best results, your altimeter should be installed in a separate payload compartment, sealed from the pressure and heat of the ejection charge gasses. While other alternatives are possible, isolating the altimeter in a protected compartment will provide the most precise readings and will keep high temperature and pressure from affecting the long-term accuracy of the instrument.

A typical payload compartment consists of a section of body tube behind the nosecone with a sealed tube coupler connecting it to the main body tube (see illustration below). Some rockets (e.g. Estes “Nova Payloader”, Quest “Zenith II”) already have such a payload section, and one can be added easily if yours does not. Use pieces of foam rubber in front of and behind the altimeter to prevent it from shifting under acceleration and deceleration and to protect it in the event of a crash. The altimeter will slide into 18mm/BT20 size body tubes, and a “sleeve” made out of standard foam pipe insulation can be used for larger size tubes. Your payload section should close securely so that the altimeter is not “ejected” upon motor burnout deceleration or chute deployment shock.



Perform initial testing of your rocket without the altimeter installed. Make sure that the parachute is ejected and opens properly so that you have a slow and safe landing. If you

conduct your preliminary tests with the altimeter installed and the chute doesn't eject, the resulting high speed ballistic descent will likely damage the altimeter (and your rocket!).

*Note: If you have any doubt about the possibility of this happening, protect the altimeter by wrapping a couple of wraps of electrical tape end to end around the battery holder. This will provide some protection to the battery holder from the relatively heavy battery in the event of an abrupt landing.*

When installing the APRA in larger rockets it may be easier to add a short (~3" long) section of BT20 tube with padded end plugs for the altimeter to ride in. The short BT20 tube could be glued to the inside of the larger airframe or to a plywood mounting plate. A static pressure sampling hole can be drilled through the main airframe and into the inner tube to allow external air pressure to get to the altimeter.

As a last resort, if accuracy isn't of paramount importance, you can simply tie the altimeter to the rocket's shock cord and pack it in along with the chute. If you must do this, observe the following precautions:

1. Use plenty of wadding between the ejection charge and the parachute.
2. Position the parachute between the wadding and the altimeter to provide additional protection from the hot ejection charge gasses.
3. Make sure the altimeter is securely tied to the shock cord so that it doesn't separate and free-fall.
4. Add a wrap of tape around the battery and jumper shunt so they don't get dislodged at ejection. *Note: Make sure the tape doesn't cover the pressure sensor (small white rectangle marked "U3") on the bottom of the altimeter.*

## ***Static Pressure Sampling Holes***

You must drill one or more clean-edged holes in the payload compartment to allow outside air pressure to be sampled by the altimeter (see table below for recommended sizes). These holes should be as far away from the nosecone shoulder and other body tube irregularities as possible (at least 3 times the body tube diameter or more) to minimize pressure disturbances being created by turbulent airflow over the body tube. Sand the area around the hole as necessary to eliminate flashing or raised edges.

Best performance and greatest accuracy will be achieved by using four smaller holes distributed at 90 degree intervals around the body tube's circumference instead of a single larger hole. When using four holes, each hole should be ½ the size of a single hole as noted in the table. This will minimize the pressure variations due to wind currents perpendicular to the rocket's direction of travel.

<i>Payload Diameter</i>	<i>Payload Length</i>	<i>Single Hole Size</i>	<i>Four Hole Size</i>
<1.5"	6"	.024"	.012" (small pinholes)
1.6"	6"	.024"	.012" (small pinholes)
2.1"	6"	.042"	.021"
3.0"	8"	.113"	.057"
3.0"	12"	.170"	.085"
3.9"	8"	.202"	.101"
3.9"	12"	.302"	.151"

*Other sizes:*

Single hole size = Diameter \* Diameter \* Length \* 0.0016

Four holes, each hole = Diameter \* Diameter \* Length \* 0.0008

# Operation

## ***Battery***

The altimeter is powered by a standard 12 volt “A23” size remote battery. Appropriate part numbers are Duracell MN21/23, GP A23, Energizer A23, and Radio Shack 23-144. Do not use a 1.5 volt “N” cell, it won’t work. Observe polarity when installing the battery – a backwards battery will not damage the altimeter, but the altimeter won’t turn on.

Exercise care when installing and removing the battery to prolong the life of the battery holder: To install the battery, hold the altimeter in one hand and the battery in the other hand. Press the “-” end of the battery against the battery holder’s spring, and swing the battery down into place. To remove the battery, use a fingernail or small screwdriver and press on the “+” end of the battery to slightly depress the spring. Raise the “+” end of the battery up and out of the holder and the battery will pop out.

## ***Power Switch***

The jumper shunt shown in the picture on page 2 is used to turn the altimeter on and off. Install the jumper shunt across the two pins on the altimeter’s circuit board to turn the altimeter on, and remove the shunt to turn it off. When the altimeter is not in use, you can place the jumper shunt on just one of the pins for storage. Make sure you use the shunt to turn the altimeter on and off – do not remove and insert the battery to provide the on/off function. Using the shunt instead will reduce wear and tear on the battery holder.

For added convenience, you can use the optional power switch cable to connect an externally-accessible on/off switch to the altimeter. The cable plugs onto the two pins on the circuit board in place of the jumper shunt, and your switch is connected to the loose ends of the cable.



## ***Powerup***

When the altimeter is turned on, it will report the peak altitude from the last flight and the current battery voltage before readying itself for flight. This is what you will hear:

- A three to six digit number (range of 160 feet to 103,500 feet) representing the apogee altitude of the last flight.  
***Note: A warbling siren tone will sound instead of the last flight altitude if power was lost during the last flight. This error will clear after the next good flight.***
- A two second pause, and then a two or three digit number representing the battery voltage in tenths of a volt (e.g. 12.2 volts would report as 122).
- A thirty second pause (giving you time to close up the rocket after turning the altimeter on), and then a periodic “chirp” approximately once per second when the altimeter is ready to launch.

While sounding the launch ready “chirp”, the altimeter will begin tracking ground level pressure, and will continuously update its internal ground reading to follow fluctuations in ground level pressure until time of launch.

**The altimeter is ready to launch at this point.**

*Do not launch before the periodic “chirp” is heard or the altimeter will not function properly!*

After flight the altimeter will report in this sequence:

- An extra-long tone to indicate the start of the reporting sequence.

- A three to six digit number representing the peak altitude in feet.
- A long separator tone followed by a two to five digit number representing the maximum velocity during the flight in miles per hour. This number, and its preceding separator, are reported in a higher pitch to differentiate it from the peak altitude number.
- A pause of 5 seconds, and then a 10 second warbling siren tone to aid in locating the rocket if it is hidden from sight in a tree, tall grass, etc.
- After a 10 second period of silence, the sequence repeats until power is disconnected. The flight's peak altitude is preserved when power is turned off, and will be reported every time power is turned on until a new flight is made.

### ***Tips for Achieving Best Accuracy***

- Use four static sampling ports instead of just one. Make sure they are sized and positioned according to the instructions in the previous section. All barometric altimeters base their altitude measurements on the air pressure surrounding the rocket, so getting a clean, turbulence-free sample is essential. A single hole, especially if it is over-sized, will introduce pressure fluctuations whenever the rocket deviates from its normal trajectory. Four evenly-spaced holes will minimize this effect.
- With a properly designed rocket and motor combination, the parachute should eject at apogee (peak altitude), when the rocket is nearly stationary. This will guarantee a minimum of turbulent airflow around the rocket, and hence the cleanest, most accurate data. If you eject your

parachute substantially before apogee, the rocket will still be traveling at a high rate of speed, which will degrade the accuracy of any possible measurements due to the massive fluctuations in pressure. In addition, deploying the chute while the rocket is traveling at high speed can potentially damage your rocket due to a zippered body tube, stripped chute, or broken shock cord.

Ejecting at apogee is best, slightly after apogee is OK, but never before apogee if you can avoid it. Ejecting before apogee will always guarantee a loss in potential altitude. It will also introduce significant degradation in altitude repeatability since the final altitude will then be determined by the (in)consistency of the motor's ejection delay.

- Use a *long* shock cord. This will allow the ejected payload section and nose cone to slow gradually rather than being jerked to a stop when the cord comes to full extension. Again, minimizing abrupt changes in the rocket's trajectory will result in the smoothest, most accurate data.

## ***Testing***

A simple apparatus for testing the altimeter can be made with a small jar and a length of plastic hose. Drill a hole in the center of the jar's lid and insert one end of the plastic hose. Glue hose in place to achieve a tight seal (hot melt glue works well).

Turn on the altimeter and place it in the jar. Tighten the lid and wait until you can hear the periodic beep from the altimeter indicating launch readiness. Suck on the free end of the plastic hose to create a vacuum within the jar. The altimeter will sense this as a launch condition and the beeping will stop. When you stop sucking on the hose, the altimeter will sense apogee as the pressure stabilizes. Open the hose and allow air to bleed back into the jar and the altimeter will sense descent. The altimeter will then beep out the "altitude" that your vacuum was able to create within the jar.

## ***Cautions***

- Do not touch circuit board traces or components or allow metallic objects to touch them when the altimeter is powered on. This could cause damage to your altimeter.
- Provide adequate padding fore and aft of the altimeter for protection in the event of a crash or excessively hard landing.
- Do not allow the altimeter to get wet. Only operate the altimeter within the environmental limits listed in the specifications section.
- Do not rupture pressure sensor diaphragm with excessive pressure or sharp object.

## Specifications:

Power:	4V – 16V, nominal 12V A23 battery
Current consumption:	1.5 ma
Battery life:	30 hours
Launch detect:	100' AGL
Maximum altitude:	100,000' MSL
Altitude resolution:	1' up to 38,000'MSL < 2' to 52,000'MSL < 5' to 72,000'MSL
Analog to Digital Converter:	24 bit Delta Sigma
Calibration accuracy:	+/- 0.05% typical
Measurement precision:	+/- (0.1% reading + 1 foot) typical
Sample rate:	20 samples per second
Operational temperature:	-40C to +85C (-40F to +185F)
Dimensions:	2.75"L x 0.55"W x 0.62"H
Weight:	0.56 oz. with battery

## **Warranty**

All PerfectFlite products include a full three year/36 month warranty against defects in parts and workmanship. Should your PerfectFlite product fail during this period, call or email our Customer Service department for information about returning your product. The warranty applies to the altimeter only, and does not cover the rocket, motor, or other equipment. This warranty does not cover damage due to misuse, abuse, alteration, or operation outside of the recommended operating conditions included with your product. Broken pressure sensor diaphragms due to puncture or exposure to ejection charge pressure/hot gasses are NOT covered under this warranty.

## **Liability**

Due care has been employed in the design and construction of this product so as to minimize the dangers inherent in its use. As the installation, setup, preparation, maintenance, and use of this equipment is beyond the control of the manufacturer, the purchaser and user accept sole responsibility for the safe and proper use of this product. The principals, employees, and vendors of the manufacturer shall not be held liable for any damage or claims resulting from any application of this product. If the purchaser and user are not confident in their ability to use the product in a safe manner it should be returned to the point of purchase immediately. Any use of this product signifies acceptance of the above terms by the purchaser and user.